

21503 Antihopping slipper clutch Ducati 899 – mounting instructions

Congratulations, you bought one of the best clutch systems for your 899.


Everytime is better when this operation is done at an experienced Ducati workshop, or mechanic.

1. Read these instructions with photos before you start. Check if the set includes all parts (pic. 21503a).
2. Remount the old clutch drum (according to the Ducati workshop manual), clean the thread on the shaft and the big nut from old glue with brake cleaner.
3. Check the positioning of the shim (STD) between the basket and drum, when you remounted it (pic a).
4. Install the premounted slipper drum (b).
5. Put the KIT steel washer as usual (c).
6. Fix the big nut (from kit) (d) with a torque of 127 Nm and fix it with glue Loctite No. 620 (e).
7. This slipper clutch is designed for using STD clutch plates. NEVER install the first friction plate with thin steel rings (judder rings) on the first position! (pic. f). Install another friction plate at first (g), then the steel plate (h), and after the friction plate with the bigger inside diameter and both steel rings (j). Install all other clutch plates in the same position as before.
8. Reinstall the STD push rod and bearing from the STD pressure plate and install it into the kit pressure plate (k).
9. Install the pressure plate (l).
10. Put the STD clutch springs in position as before, put the spring kit-bushings, fix all with M5 bolts with a torque of 8 Nm (m,n).
Check the correct clearance between the pressure plate and the clutch hub in the bore in the pressure plate. The correct clearance is ca. 1.0-1.2 mm. Minimal clearance is 0.5mm, in case it is smaller, change all friction plates. You can optimize good clearance by using different thicknesses of steel plates – 1.6mm and 2.0mm.
11. Everytime use a new clutch cover gasket.
12. Mount the case cover according to the Ducati workshop manual.

LIST OF PARTS

- 1 pc. clutch drum premounted
- 1 pc. pressure plate
- 5 pcs. spring retainers
- 5 pcs. spring retainers for more preload
- 5 pcs. bolt M5

21503 Picture A (pic.a)




21503 Picture B (pic.b)



21503 Picture C (pic.c)



21503 Picture D (pic.d)




21503 Picture E (pic.e)




21503 Picture F (pic.f)




21503 Picture G (pic.g)




21503 Picture H (pic. h)




21503 Picture J (pic.j)




21503 Picture K (pic. k)



21503 Picture L (pic.l)



21503 Picture M (pic. m)



21503 Picture N (pic. n)

